

QUICK GUIDE

DEVICE INFORMATION

SETUP DIAGRAM

REMOTE CONTROL

REMOTE CONTROL

- 1 Dongle
- 2 Quick Guide
- 3 Remote Control
- 4 Power Adapter
- 5 Battery
- 6 Power Cable

- 1 HDMI
- 2 DC 5V

Do more on your TV with your voice

Search for shows, get recommendations, even control your TV - faster - with your voice. Ask Google for a little help on your big screen.

Pairing guide

Long press Back+Home button at the same time, until the red light flashes quickly, then release, that means RCU enter the pairing mode. Waiting for few seconds and stop pressing any buttons, until it pop up the message of pairing successfully.

ANDROID TV

ANDROID TV

SPECIFICATION

SAFETY INFORMATION

Complete the on-screen setup

Follow the on-screen instructions using your remote to navigate through the setup process.

Android TV brings a world of content to your biggest screen. Ask Google to search for the latest blockbuster, stream shows, or open multiplayer games. Have it dim the lights by connecting smart home devices. Manage tasks and see your calendar. Or ask it questions and see the answers on your TV. Press the Google Assistant button on your remote to talk to Google.

Hardware	
Chipset	Amlogic S905Y2
RAM	2Gb
Flash	eMMC 8GB
Video	
Video Decoding	VP9 Profile-2 up to 4Kx2K@60fps H.265 HEVC MP-10@L5.1 up to 4Kx2K@60fps AVS2-P2 Profile up to 4Kx2K@60fps H.264 AVC HP@L5.1 up to 4Kx2K@30fps H.264 MVC up to 1080P@60fps MPEG-4 ASP@L5 up to 1080P@60fps (ISO-14496) WMV/VVC-1 SP/MP/AP up to 1080P@60fps AVS-P16(AVS+) /AVS-P2 Jizhun Profile up to 1080P@60fps MPEG-2 MP/HL up to 1080P@60fps (ISO-13818) MPEG-1 MP/HL up to 1080P@60fps (ISO-11172) RealVideo 8/9/10 up to 1080P@60fps
Video File Format	Support *.mkv, *.wmv, *.mpg, *.mpeg, *.dat, *.avi, *.mov, *.iso, *.mp4, *.rm, *.jpg, *.bmp, *.gif etc...
Video Output	HDMI 2.1 . HDCP2.2
Aspect Ratio	Auto, Full screen
Video Resolution	4K, 1080p/i, 720p
Power	
DC Input Range	5V/1A
Power Consumption	Maximum 5 W

CAUTION! **NOTICE:** To prevent fire and electric shock, do not expose this receiver to rain or moisture. In order to avoid any possible risk of electric shock, never attempt to open the unit. In case of the unit breaking down, repair of the unit should be carried out by qualified technicians. No part of this unit should be repaired by users.

WARNING!

- Place the receiver in a well-ventilated location to prevent accumulation of internal heat.
- Protect the receiver from high temperatures, humidity, water and dust.
- Do not place any objects that might damage your unit near it (e.g. liquid filled objects or candles).

Google, Google Play, YouTube, Android TV and other marks are trademarks of Google LLC.

Google Assistant is not available in certain languages and countries.