



Shenzhen Trigon Technology Co., Ltd.  
www.trigon.com.cn

- 料号: BC06-100870-0B (英语)
- 尺寸: 125x200mm
- 材质:  128g铜版纸
  - 封面128g铜版纸; 内页70g书纸
- 工艺:  黑色印刷
  - 黑色印刷, 表面过油
- 厂家:

■ 设计: 邓婷婷 2021/06/08

■ 审核:

AB IPBox

LINUX SATELLITE RECEIVER

DVBS2X













ONE<sup>®</sup>









User manual





|   |  |
|---|--|
|    | <p>Digital video broadcasting logo.</p> <p>This logo informs that the receiver conforms to the Digital Video broadcasting standards.</p>   |
|    | <p>Risk of electric shock - do not open.</p> <p>This notice warns the user not the receiver housing. The housing may be opened solely by authorized service technicians.</p>   |
|    | <p>When this crossed-out wheeled bin symbol is attached to a product it means that the product is consistent with European Directive 2002/96/EC.</p> <p>Please inform yourself about the local separate collection system for electrical and electronic products.</p>  |
|    | <p>Please act according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.</p>  |
|  | <p>Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.</p> <p>Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.</p> |
|  | <p>Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.</p>   |

|   |  |
|---|--|
|    | <p>The logo informs that the receiver is consistent with terms and conditions of Directive 2004/108/EC concerning observance by Member States of provisions regulating electromagnetic compatibility, and to the terms and conditions of Directives 2006/95/EC concerning observance by Member States of provisions regulating low voltage electricity and safety with relation to the handling and operation of electrical equipment.</p> <p>This product has been designed, tested and manufactured according to the European CE Directive 2014/53/EC.</p> |
|    | <p>This logo informs that the receiver is an electrically safe device, provided that it is used in accordance with the recommendations set forward in the chapter concerning safety.</p>   |
|   | <p>Caution: Hot surface. Do not touch. The top surface over the internal heat sink may become hot when operating this product continuously.</p> <p>Do not touch hot areas, especially around the 'Hot surface mark' and the top panel.</p>   |
|  | <p>When this logo is attached to a product, it means a financial contribution has been paid to the associated national recovery and recycling system.</p>  |

|   |  |
|---|--|
|    | <p>To avoid electric-shock hazards, do not open the housing, refer servicing to qualified personnel only.</p>  |
|    | <p>Do not expose the receiver to direct sunlight. Keep it away from the heat source.</p>   |
|    | <p>When the abnormal phenomenon occurs, you should cut off the power supply immediately.</p>   |
|    | <p>Switch the receiver off whenever it remains out of service for an extended period.</p>  |
|    | <p>Keep the receiver away from flower vases, tubs, sinks, etc., in order to avoid damaging the equipment.</p>  |
|   | <p>Do not block ventilation holes of the receiver so air can circulate freely.</p>   |
|  | <p>Do not touch the receiver during thunder, since that might create electric-shock hazards. It is recommended to cut off power supply.</p>  |
|  | <p>Be sure to turn the receiver off and disconnect the AC power cord before cleaning the receiver surface.<br/>If the surface is dirty, wipe clean with a wetted cloth and wrung out thoroughly, then wipe again with a dry cloth.</p> |

## Contents

|                                 |    |
|---------------------------------|----|
| Contents .....                  | 06 |
| Major features .....            | 07 |
| Packing contents .....          | 08 |
| Front & Side Panel .....        | 09 |
| Rear panel .....                | 10 |
| Remote Controller (RCU) .....   | 11 |
| First start .....               | 13 |
| How to update your system ..... | 22 |
| Live TV .....                   | 27 |
| Service Scan .....              | 29 |
| Satellite .....                 | 29 |
| Channel List .....              | 30 |
| Channel Info .....              | 32 |
| More Info .....                 | 33 |
| PVR .....                       | 35 |
| Time Shift .....                | 36 |
| Program Guide .....             | 37 |
| Add timer .....                 | 48 |
| Channel Editor .....            | 39 |
| Setup .....                     | 42 |

## Major features





- Support 4K resolution and 4K(10bit) channels.
- Operating System : Android.
- Satellite Tuner (DVB-S2).
- Support Android TV Launcher.
- Support PVR, Timeshift features: USB HDD, USB memory stick, NAS.
- Extended EPG and program reservation on EPG .
- Support H.265 HW decoding.
- Support Webserver, NAS, samba, UPNP.
- Support 2.4G Wire Mouse and Key board.
- Support Closed Caption/Teletext/DVB-Subtitle.
- Built-in WIFI /Bluetooth.

## Packing contents



- 1 Set-Top Box with WIFI
- 2 Remote Control Unit
- 3 HDMI cable
- 4 2 batteries for RCU ( AAA x 2pcs )
- 5 Power Adapter
- 6 Quick Install Guide

## Front & Side Panel




1 TFT LCD : To show working status.

2 USB 3.0 / 2.0 port :

To support USB 2.0 device like USB Stick, HDD Camera etc.



## Rear panel



### 1. Satellite

Connect the cable from Satellite

### 2. AV Receiver Connection

Use an AV receiver for better audio quality. Connect the receiver's SPDIF connector to the AV receiver's digital audio input connector using an optical audio cable.

### 3. HDMI Connection

Connect the receiver's HDMI output connectors to the TV's HDMI input connector using an HDMI cable.

### 4. Network Connection

Connect the receiver LAN port to the router using a network cable. For details, please refer to the Network Settings on.

### 5. Power Up

A power cord with an adapter is provided in an accessory.

Plug the round end of the adapter power cord into the power input.

### 6. Smart card reader

## Remote Controller (RCU)



### Programmable Remote part

How to program for TV RCU button (Example: Power button) :

1. Press "SET" key for 3 seconds, the red light on.
2. Press "POWER" key in TV CONTROL area in 10 seconds, the red light flash.
3. Keep TV remote IR and STB remote IR face to face in 3cm, press "POWER" key on TV remote, the red light flash 3 times and keep lighting, learning successful.
4. Repeat step 2 and 3 to learn other keys.  
Press "SET" key again to exit learning status.

## STB part

1. POWER : To control STB power.
2. Digit 0 ~ 9 and . : to put channel number / IP address etc.
3. Back Space : To delete word.
4. Next/Previous file : Move to next or previous file.
5. Resolution : Change resolution of 720p,1080i,1080p,2160p.
6. Mute : Sound Mute.
7. Rewind : Rewind Media.
8. Play/Pause : Pause/Play Media.
9. Stop : Stop to play/record Media.
10. Fast Forward : To move Fast forward.
11. TV Guide : Electrical program Guide.
12. INFO(i) : Information for TV channel.
13. Exit : Exit or Back.
14. Menu : to load Menu in Apps.
15. Home : Go Android Home.
16. Vol +, - : To increase/decrease volume.
17. CH +, - : To change channel.
18. Color buttons : to use specific function in App. E.g. in Live TV app yellow button- Subtitle/Teletext, green button-Sound, red button-Popup Menu.
19. Apps: To call Android App list.
20. Mouse : Change Mouse mode.
21. Resolution : Change Ratio of 4:3, 16:9.

## First start


This document explains how to install the latest software and initial usage after purchasing the product.

We have taken screenshots in English in consider ration of the global character of this manual, and the captured pictures may be different from the personal environment.


After purchasing the product, connect the TV and AB IPBOX box with the HDMI cable, connect the DC power adapter to turn on the power.

When you turn on the AB IPBOX box, the following screen appears.


Enter your desired language:




This option is only available in English:




you can set your network, including Wifi settings.




The device then checks for available updates.





Sign in with your google account.




Enter your password:




Use the virtual keyboard to enter your login details.



## Accept Terms of Service:






## Location:






## Help improve Android performance:






Now your device is set up and ready to use:




Go to the Setting:




The wired Internet connection is recommended for smooth use of this product.  
The WIFI connection is explained below.

Start screen of Settings-Network.




If “Settings” option is selected, the following screen is displayed.



WIFI connection is off by default. If you want to use WIFI, turn on this function and choose our network. Once the network cable is connected, you can check the IP address as shown in the screen below.

If you do not use WIFI, you do not need to read this section. When you specify the WIFI Network to use, the Setting page with the password is displayed.

Please enter your password.




If you set all the passwords, Press “NEXT”.

## How to update your system

You'll see two items in the settings, as shown below:

- Online Upgrade.
- USB Upgrade.



Select "Online Update"

There are 2 update modes available in System Update:

Update: standard software update.

Online reinstallation: ATTENTION - selecting this item will delete all applications for you. This is a reinstallation of the full system.


Update options:

Full version: Clears all data, including applications.


Normal version: Preserves installed applications.




When the download is completed as shown below, the AB IPBOX box will reboot automatically and the upgrade will start with the downloaded image.




Press OK button.



The following screen will change to Android Software upgrade mode.



When the process is completed, the AB IPBOX box will proceed with the reboot.




You have just upgraded your system. Set up your local / personal user interface before using the product. After completing the basic update, continue with the following basic configuration.



When using the Home Launcher, the main application and user application are listed in the middle of the screen.

There are applications to go to the app that you frequently use with the remote control. If you want to change the order of this app, place the cursor on the desired application, press "OK" key for 3 to 5 seconds.

Please select an application icon that you want to move, place the icon to desired location. Press the "OK" button.




You are now roughly finished with the default settings. It is time to install the default app you need.

The Android for TV differs from the Google Play in general Android Google Play.

So, the fact that some regular mobile Android app does not work in AB IPBOX box is normal. To complement that you can not find mobile Apps in AB IPBOX box. So we also provide "Market" to find other Apps. This is a backup App to replace the Google Mobile App Store.

## Live TV

User Preferences explains the menus provided by Live TV.



This is the main screen configuration of the application.

When running for the first time, there is no channel, so it moves to the main screen.


1. Live TV : Watch live TV when there is a saved (scanned) channel.
2. Scan : Search for channels.
3. Setup : Live TV system configuration and channel data backup/restore.
4. Exit : Exit the Live TV application.



## Service Scan

### Satellite

Search: Satellite



#### 1. Search Mode:

- Preset Scan : Scan by pre-programmed TP information.
- Blind Scan : Scan by tuner input signal.
- Manual Scan : Scan by manual TP information.
- Fast Scan : Scan by manual TP information.


#### 2. Select Satellite for scanning.

#### 3. LNB Type : Select LNB that you are using.

#### 4. Switch Setup : Select proper switch for antenna.


#### 5. Press Red button to scan.

#### 6. After scanning channels, press "Exit" button, then channel will be stored and go to Live TV to enjoy Live TV channels.




## Channel List

Press "OK" on RCU, You can manage channel list.



Press “left” arrow button on RCU, You can manage Simple channel list.





Press “right” or “ ← ” button on RCU, You can manage Recall list.



## Channel Info

When you change channel, you can see channel information.


If you want to see more information with detail EPG, press “info” button twice.




Then you can use Arrow key to choose some function like Sub-menu, Timer, Record, Record list, Lock, Subtitle, Teletext, Audio sound.

1. Timer list: Add / Remove timer for recording or reminder.
2. Recording: Start recording.
3. File list: Play recordings.
4. Channel lock.
5. Subtitle / Teletext: To use the subtitle / teletext function.
6. Left / Right sound: For left / right control.

## Subtitles /Teletext



## Timer




## More Info

Press RED button in LIVE TV mode. Then you can see Popup Menu.


- Go to the main menu.
- Color settings: Control the colors of the Box.
- Display Area Setting: Adjusts the OSD display area.
- Streaming: Used to completely record 1 transponder.






### Color Adjustment:

Adjust the color of the TV.




### Adjust the OSD area:

Adjust the OSD on the TV.





### Streaming



## PVR

To record channel, On live mode, press “ ● ” button then you can see recording menu.

Select option like duration, storage device. Then press “Start” button then will start recording.




## Time Shift


To use Time shift function, you need to designate storage.

- Enable Time Shift.
- Designate Storage device.



After setting Time shift function,

To use time shift function, in Live TV mode, press “  ” button then you can enter time shift mode.



In time shift mode, you can use     button to control for Timeshift feature.

## Program Guide

World Fashion Channel  
75.0E-ABS2\_2A 12100 MHz / 45000 KSym/s V

03/12/2021 | 16:38

**Модные показы [16+]** Fri, 16:30 ( 00:15 )

Добро пожаловать на первый ряд лучших показов текущего и будущего сезонов. Телеканал WorldFashion приглашает вас насладиться самыми яркими шоу мировых подиумов.


|     | Fri, 12/03          | 16:00                             | 17:00                                     | 18:00                                |
|-----|---------------------|-----------------------------------|---|--------------------------------------|
| 346 | World Fashion Ch... | Модны... Стиль з...               | Модны... Имена [...                       | Модны... Выбор р...                  |
| 347 | History 2           | Вселенная: Древние тайны...       | Воздушные бои. 11-я серия...              | Охотники на НЛО. 8-я серия... Дре... |
| 348 | Russian Extreme...  | SOS. "Македония", 1-я серия [16+] | Куда уж дальше. "... Мир без виз: вокр... | В гостях у Макса... Чемпионат ми...  |
| 349 | Канал Disney        | Доброе утро с Микки [0+]          | П...                                      |                                      |
| 350 | Ю                   | Барышня - Крестьянка [16+]        |   | Супер                                |

● Multiple/Single   
 ● Previous   
 ● Next   
 ● Reminder   
 ● Recording   
 🕒 TimerList

It allows:

1. RED button.: Switches between single and multi EPG display.
2. Green Button: Displays the EPG from the previous day.
3. Yellow button: Displays the EPG from the next day.
4. Blue Button: Reserves an EPG event to watch.
5. Button Recordings: Adds a timer for the EPG event.
6. 🕒: Displays a list of timers.


## Add timer

- In the EPG, use the button  (located in the lower left corner on the remote control) to call up the list of timers, press the green button "Add timer".
- You can select "View" or "Upload".
- Set the channel / time / duration / storage to record a channel or box switch to a channel.




## Channel Editor


In the channel list, press the “i” button to display the channel editor. Then the green button and select the channel editing option.



**Edit Group List:** Enable/ Disable Favorite/ Provider/ FTA/Scramble/ HD/ UHD.




## Make Favorite Groups/Channels: Add/ Rename/ Move Favorite channels.




## How to create a FAV group

In the channel list, press the “ i ” button to display the channel editing options. Then the green button and select your favorite channels option.




In the left window, select the desired FAV group using the ▼ / ▲ buttons. Use the ➔ button to move to all channels and use the green button to add the desired programs to the selected FAV group. Repeat the procedure to create another FAV group.

**Skip Channels:** Select channel to skip in list.




**Delete Channels:** Select channel to delete in list permanently.





**Lock/Unlock Channels:** Select channel to lock in list.



## Setup


• **Language:** Select the default language.

1. Audio/ EPG Language : Select the default playback audio language.



• **Preference:** Set the Live TV function settings.

1. Boot Startup: Sets the TV to appear automatically at startup.  
(Disable: Do not use / Enable: Use)
2. Power Mode: Set the operation when the remote control power button is pressed. (Standby: Power Standby Mode/ Power Save: Power Off Mode)
3. Time source: Set the time display method. (Internet: Check mark time using network/ Satellite: Check mark time using satellite signal)
4. External EPG (xmltv.xml): Loads an xml-based external EPG.  
(Disable: Do not use/ Enable: Use)
5. Information on the LCD display.
6. Audio Out Weight: Adjusts the TV volume level.  
(You can specify from 30 to 100)
7. L/R Arrow key setting: Set the operation method of left and right arrow keys. (Sound control : Volume up & down / Show channel list : Simple channel list and history list)




- **User Interface:** Set up the user interface.
1. **Infobar Timeout:** Set the time the infobar disappears when switching channels. (You can specify from 1 to 10 seconds)
  2. **Info box Transparency:** Set the transparency of the info box. (0% ~ 50% can be specified)
  3. **ChannelList Background Color:** Set the channel list background color.
  4. **Setup Background Color:** Set the background color of the configuration page.
  5. **Main Background:** Select the main menu background image.
  6. **Menu Skin:** Select the main menu skin type.
  7. **EPG Action:** Set the action method when the OK button is pressed in the EPG window. (Watch channel: Watch channel/ Set Time : Add timer)




• **Backup:** You can back up channel and user data and restore it when the device is initialized.

1. Backup channel data to storage : Backup channel data to USB storage.
2. Restore channel data from storage : Recovers channel data from USB storage.
3. Backup user data to storage : Backup user data to USB storage.
4. Restore user data from storage : Recover user data from USB storage.




- **Access Control:** Initializes system access control.

1. Set Pin Code: Set the pin code. (Initial pin code is 0000.)
2. Scan Menu : Set the permission to access the Start menu. (Unlock / Lock)
3. Rest : Set the access authority of the Rest menu. (Unlock / Lock)
4. Backup : Set the access authority of the backup menu. (Unlock / Lock)



- **Reset:** Channel-related data and factory reset.

1. Reset Channels Data : Deletes all searched channel data.
2. Initialize User Favorites : Initializes the user favorites list.
3. Reset Channels EPG Data : Initializes EPG data.
4. Clear Timers : Initializes the timer data.
5. Reload group : Restores the channel group.
6. Factory Reset : Performs factory reset.



- **LCN:** Set the LCN number.

1. Local Channel Number(LCN) : Use the local channel number.

(Disable : Do not use / Enable : Use)

2. LCN User Number : Designate the NCL user start number.

